Fitting Instructions – Millhouse Brass Cabinet hardware - Knobs

Date Modified: 07/03/2025

Last modified by: Brock Hutchins

For best results when fitting Millhouse brass cabinet hardware follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:
1x Cabinet furniture
1x Backplate (optional – you may not have purchased this item)
1x M4 bolt through fixings

Recommended tools

- PH2/flat head screwdriver
- 4mm drill bit
- Drill – Cordless or corded

1) First, mark out the desired position of the hardware items.
2) Drill out locations of the bolt through fixing.
3) If fitting with backplate, insert the screw/screws into the hole you have drilled and then using the protruding screws, locate the backplate, and then the item cabinet hardware itself.
4) Screw in the bolt through fixings, its recommended that you hold the knob when screwing it in to prevent it spinning