Fitting Instructions – Millhouse Brass Cabinet hardware – Single point fixing T-Bars

Date Modified: 07/03/2025

Last modified by: Brock Hutchins

For best results when fitting Millhouse brass cabinet hardware follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:
1x Cabinet furniture
1x M4 bolt through fixings

Recommended tools

- PH2/flat head screwdriver
- 4mm drill bit
- 1.5/2mm drill bit (brad point recommended)
- Drill – Cordless or corded

1) First, mark out the desired position of the hardware items
2) Drill out locations of the bolt through fixing.
3) Put in the bolt through fixing in the hole and start to tighten the screw up until the point contacts the wood. Remove the piece of hardware
4) With the mark the spike made, and using the smaller drill bit, drill out 2/3mm deep, this will create enough clearance for the spike to fit in without damaging the surrounding cabinet face.
5) Screw in the bolt through fixings, ensuring the spike goes into the hole that has just been drilled.