

Fitting Instructions – Millhouse Brass Cabinet hardware

Date Modified: 04/03/2025

Last modified by: Brock Hutchins

For best results when fitting Millhouse brass cabinet hardware follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

1x Cabinet furniture

1x Backplate (optional – you may not have purchased this item)

2x or 1x M4 bolt through fixings

Recommended tools

- PH2/flat head screwdriver
- 4mm drill bit
- Drill – Cordless or corded

- 1) First, mark out the desired position of the hardware items – these change between items
Codes that include 128, 160 and 320 have 128mm, 160mm and 320mm Center to Center fixing points respectively
All others have a single fixing point.
- 2) Drill out locations of the bolt through fixings
- 3) If fitting with backplate, insert the screw/screws into the hole you have drilled and then using the protruding screws, locate the backplate, and then the item cabinet hardware itself.
- 4) Screw in the bolt through fixings, with hardware that has 2 screws, its recommended that you go between the 2 screws and keep the handle as level to the door front as possible, so they don't bind up.

