



Fitting Instructions – Atlantic Cylinder Premium Floor Mounted Door Stop

ADSCP

Date Modified: 20/02/2024

Last modified by: Brock Hutchins

For best results when fixing a floor mounted door stop follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 Door stop

X1 Plug

X1 Screw

- 1) First, mark out the position of the door stop on the floor.
- 2) Remove the top of the door stop by unscrewing it.
- 3) Drill the hole in the desired location on the floor, ensuring that you don't hit any utilities running below.
- 4) Insert the plug into that hole and screw into place.
- 5) Open door and check for placement.