atlantic uk
architectural hardware

Fitting Instructions – Atlantic Kick Plate Pre Drilled with screws

KICK PLATES

Date Modified: 20/09/2022

Last modified by: Brock H

For best results when fixing a kick plate follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:
X1 Kick Plate
X8 Screws

1) First, mark out the desired position of the kick plate on the bottom of the door. Make sure to leave 2mm clearance between the bottom of the kick plate/door.
2) Now, centralise the kick plate with the door.
3) Then, drill out pilot holes for the screws.
4) Finally, fasten into place using the screws provided and make sure to remove the protective covering.