

Fitting Instructions – Old English Cabinet Hardware

Date Modified: 01/10/2025

Last modified by: Brock Hutchins

For best results when fitting Old English cabinet hardware follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

1x Cabinet furniture

1x fixing pack

Recommended tools

- PH2/flat head screwdriver
- 4mm drill bit
- Drill – Cordless or corded

- 1) First, mark out the desired position of the hardware items.
- 2) Drill out locations of the bolt through fixing.
- 3) If fitting with backplate, insert the screw/screws into the hole you have drilled and then using the protruding screws, locate the backplate, and then the item cabinet hardware itself.
- 4) Screw in the bolt through fixings, its recommended that you hold the knob when screwing it in to prevent it spinning